

Using a clock face as a guide and with the inlet at the 12 O'Clock position, the best place for the overflows is at 12 O'Clock or 6 O'Clock but can be fit elsewhere if required.

The brass outlet can be positioned anywhere around the base of the tank.

