

## Gotboost Performance Nissan R35 GT-R Fire Extinguisher Mount Installation Guide

First off, tuck the fabric apron that hangs down at the front of the seat up and towards the rear of the seat.

1. Pull at lower front of the plastic trim on the right side of the passenger seat. It is held with post fasteners that will release with some force. You don't have to remove the whole panel....you just need the front part loose.
2. Pull down the trim panel as shown.



3. This is the 8mm hole already in the steel seat frame that is not being used for anything. It is at the tip of my index finger. This is where the end of the s bent bracket will be fastened.



4. There is a triangular bracket that is not being used for anything that is under the left forward part of the seat. This is where the L shaped rounded bracket fastens. There is a 6mm hole towards the front of it. The tip of my finger is on it.



5. Start by fastening to the triangular bracket. Use a 1/4"x 3/4" hex bolt, washer and go through the bottom of the L bracket on the mount, and up through the 6mm hole at the end of the triangular seat bracket. **YOU MUST THREAD THIS IN LIKE IT IS A THREADED FASTENER BECAUSE THE FACTORY SEAT HOLE IT UNDERSIZED A TEENY BIT FOR A 1/4 BOLT.** It will thread in by hand very easily. This is what it should look like. **DON'T TIGHTEN YET!** Stick a washer, split washer and nut on the end of the bolt now.....again don't tighten yet.





6. Take the other 1/4"x3/4" hex bolt and double over some masking tape on your right index finger. Stick the hex bolt onto it like this.



7. Swing the s shaped bracket end on the mount over and move the end with the hole up into place where the 8mm hole is on the side of the seat frame. Take the bolt on the end of your finger and feed it through the backside, out through the hole and hole in the mount. It takes a little contortion but not too bad. Go up through the front bottom of the seat with your finger Easier to do this than to try and go the other direction and fish a nut on the backside. This is what it should look like when finished.



8. Place a washer on the hex bolt along with a split washer and nut. You can get a wrench on the backside and then tighten the s mount side. 7/16" ratchet wrench is really helpful doing this install, but not needed. You can tighten this now.



9. Tighten the L shaped bracket on the other end of the mount by tightening the hex bolt first, and then the nut and lock washer. Finish by snapping the trim back into place. It should look like this.....ready for an extinguisher.



Extinguisher mount is compatible with 2.5 lb Amerex brand extinguishers. Amerex has dealers all over the world and are one of the largest extinguisher manufacturers. [www.amerex-fire.com/products](http://www.amerex-fire.com/products)

Model Numbers:

B385TS - Halatron

B385TSC - Halatron Chrome

B417T - Dry Chemical

B417TC - Dry Chemical Chrome

