

Copy

Letter of warranty



You
Tube

www.youtube.com/BulletHDCam



www.facebook.com/BulletHDCam



BIKER MATE

Riding Camcorder

Welcome

- Thanks for purchasing BulletHD BIKER MATE
- Please read this instruction manual to ensure correct use of the product prior to use.
- Please keep this instruction manual in a safe place.
- Please ensure that the sales store fills out the warranty with the date of purchase and the name of the store.
- The warranty does not cover any damage that may occur during any activity. It is the users responsibility to secure the action cam securely to any equipment.

Contents


WHAT'S INCLUDED-----	P3
BIKER MATE OVERVIEW-----	P4
LED Status-----	P6
Initial Set Up-----	P6
Charging The Battery-----	P7
Engine Start Mode-----	P7
Power On/Off By Pressing Button-----	P7
Card Slot Empty-----	P7
Basic Settings Via SETTINGS.TXT File-----	P8
Storage Chart-----	P8
Take a Video (Manual)-----	P9
Playback On Your Computer-----	P9
On a Mac-----	P9
Important Tip For MAC Users-----	P9
Technical Specifications-----	P10
Warranty-----	P11
Warning-----	P11
Warranty Card-----	P13

WHAT'S INCLUDED




1. Main Controller
2. Main Controller Flat Mount
3. 3M VHB Adhesive Type-A
4. Optic Nerve Cable 78 Inch (2 Meter)
5. Interchangeable Lens Module
6. 360 Lens Flat Mount
7. 3M VHB Adhesive Type-B
8. Dual USB Power Converter (DC 12V to DC 5V)
9. USB Cable
10. Cable Connector * 2 Pieces

BIKER MATE OVERVIEW



12. Recording Indicator LED



16. 12V Power INPUT

15. Waterproof Fuse Box

17. Power Indicator LED

18. USB Power Output #1

19. USB Power Output #2

LED Status

Status Table	Recording Indicator LED	Charging Indicator LED		Status Indicator LED		Buzzer
LED Colour	RED	RED	BLUE	RED(1080P)	BLUE(720P)	-
Power On	On	On	Flashing	On	Off	3 Times
Standby	On	On	Off	On	Off	Off
Taking Video	Flashing	On	Off	Slowly brighten, then slowly turn dark	Slowly brighten, then slowly turn dark	1 Time
Stop Video	On	On	Off	On	Off	2 Times
Card Slot Empty	Fast Flashing	On	Off	Flashing	Flashing	2 Seconds
MicroSD Card Full	Fast Flashing	On	Off	Fast Flashing	Flashing	4 Times
Battery Charing	On	On	Off	On	Off	Off
Low Battery	On	On	On	On	Off	Off

REMARKS:

THE SPECIFICATION IS SUBJECT TO CHANGE WITHOUT NOTICE.

Initial Set Up

1. Please ensure the camcorder is OFF before insert or take out the Micro SD card!
2. Open the Micro SD card slot cover.
3. Install a micro SD memory card (max up to 64GB(FAT32)) into the card slot.
4. If no micro SD memory is inserted in the BIKER MATE, the Status Indicator Light will blink red and blue.
5. When using a micro SD memory card in the BIKER MATE, there should be no data from other devices on the card. If you are using a micro SD memory card for the first time in the BIKER MATE, first you should format the card in your computer.

Charging The Battery

There is built-in battery inside the BIKER MATE. The RED color charging LED turns on while charging, goes off when the battery is fully charged. The BLUE color LED flashing while battery power is low.

Engine Start Mode

Turn ON BIKER MATE	Once installed the Power Converter on your bike, BIKER MATE starts REC after engine is started.
Turn OFF BIKER MATE	When you cut the engine, it stops recording and saves the recorded files automatically without pressing button.

Power On/Off By Pressing Button

Turn ON BIKER MATE	Turn ON the BIKER MATE by pressing the Power button once. Then, the red LED will be flashes. The BIKER MATE will beep 3 times, indicating that it is in standby mode.
Turn OFF BIKER MATE	Turn the BIKER MATE off by pressing the Power button in standby mode for at least 2 seconds. The red LED flashes. The BIKER MATE will beep 6 times .Then the LED turns off, indicating that it switches off.

Card Slot Empty

If there is no Micro SD card in the camera, the red and blue LED will flash for 30 seconds. Then, the camera will switch off automatically.

Friendly reminder: Please insert the Micro SD card before using the camera!

Basic Settings Via SETTINGS.TXT File

You can also change the settings via the SETTINGS.TXT file, the file will be created automatically on the micro SD card after the camera is turned ON.

You can even type your Name on the screen of video.
For example: My-Harley-Davidson

Settings	Parameters	Remarks
#####		
#system setting		
#####		
VERSION	= BM0015042403	# can't change
RESOLUTION	= 0	# (0=1080p, 1= 720p@60fps)
VIDEO_TIME	= 2	# (0=5mins, 1=10mins, 2=15mins)
recording chunk time		
QUALITY	= 0	# (0=fine, 1=good, 2=normal)
LOOP_RECORD	= 1	# (0=off, 1=on)
DATE_STAMP	= 1	# (0=off, 1=on)
G-SENSOR	= 0	# (0=high, 1=mid, 2=low, 3=off)
AUDIO_RECORD	= 1	# (0=off, 1=on)
AUTO_POWER_OFF	= 1	# 0=Off, 1=3min, 2=5min, 3=10min
TIME_SET	= N2015.01.01.00:00:00	# Y=change N=not change
DEFAULT_SETTING	= 0	# (0=false, 1=true) when set to 1, the
camera will ignore other settings, set to system default and write the default settings in this file		
CAMERA_NAME	= BIKER-MATE	# Device ID
#####		
#end		
#####		

Remember to insert a micro SD card before you start taking videos!

Storage Chart					
Mode	Video				
	4GB	8GB	16GB	32GB	64GB (Fat32)
1080P @30FPS	33 mins	60 mins	120 mins	235 mins	470 mins
720P @60FPS	37 mins	70 mins	140 mins	270 mins	530 mins



Take a Video (Manual)

Turn on the BIKER MATE by pressing the Power button. Press the recording button to start a video recording. The red LED will blink while the video is recording. Press the recording button again to stop recording.



Playback On Your Computer

Power off the BIKER MATE! Connect with your computer via USB cable from the USB port, then turn on the device! The camera will be recognized automatically as USB Device. Or you can take out the micro SD card and use your own card reader to connect with your computer too.



The device must be power on while connected with computer for data download.

Caution!

Do not remove the USB cable under "Mass Storage" status! Please switch off the camera before removing the USB cable!

On a MAC

Simply plug the BIKER MATE into your MAC via USB cable, turn ON the BIKER MATE, and the MAC OS will recognize the BIKER MATE as an external hard drive.

Important Tip For MAC Users

When deleting files from your MicroSD cards you must empty the trash before removing it or unplugging the BIKER MATE. If you do not empty your trash the photos and videos files will not be completely erased from your cards.

Technical Specifications

Optics:

- FISHEYE view @1080p (default) Mode
- Ultra Wide Angle view @720p Mode
- f/1.8, fixed focus glass lens
- Optical lens: ø17mm FISHEYE Lens
- Lens Construction: 5 Elements

Video:

- Full HD Resolution Settings: 1080p: 1920x 1080 @ 30fps
- HD Resolution Settings: 720p: 1280x 720 @ 60fps
- Digital Video Motion Stabilization Technology
- Anti-Shaking (Stabilizer)
- Video Format: H.264 (avc1) / MOV
- Exposure Control: Auto
- White Balance: Auto
- G-Sensor

Audio:

- Built-in microphone

Storage:

- Memory: Micro SD card (Not included), up to 64GB (Fat32) capacity (recommended Class 6 or above)
- Avg. Record Time: 5~10min/GB

Operating System (for USB drive): WIN XP, 7, 8, Vista; Mac OS X 10.8.4+

Warranty:

As the warranty is included within this instruction manual, please ensure that the store name and date of purchase are filled in. Please read the warranty carefully and keep it in a safe place. This product is covered by a 365 days Limited Warranty on parts and labor from the date of original purchase, and purchases must be made through an authorized dealer. The warranty covers defects in workmanship and materials. The warranty does not apply to units, which have been damaged or abused intentionally or unintentionally. Purchase from individuals or unauthorized internet sites voids the warranty. The warranty does not apply to units where the rear cap was incorrectly closed, cosmetic damage, modification of or to any part of the product.

Tampering with or altering the unit will void the warranty. Any unauthorized service will void the warranty. Original sales receipt must be produced for any warranty service and a return authorization must be obtained from our customer service points.

The warranty does not cover any damage that may occur during a sport activity. It is the users responsibility to secure the BullethD securely to any sport equipment.



WARNING:

The form and functions of BULLETHD, accessories, logos, and all graphics are the patented, protected property of Silver Creation International Ltd. Any attempt by anyone other than our authorized dealers to copy or reproduce any of the above without permission of *Silver Creation Int'l Ltd.* will be met with legal action. *Silver Creation Int'l Ltd.* products are available for purchase only from authorized dealers.

END



Shoot and share video at



www.BulletHD.us

V3.0 BulletHD BIKER MATE UM English

Technical changes and mistakes reserved!

**Due to rapid technical development, products are under constant changes / improvements
- please check www.BulletHD.us for current updates.**



WARRANTY CARD

This warranty is a guarantee that repairs will be carried out free of charge as per the information on the date of purchase during the period set out below until damage occurs.

Customer details

Name: _____ Mr. / Ms.

Tel: _____

Address: _____

Model Number: _____

Serial Number: _____

Information on BulletHD's products
can also be seen on the homepage:
www.BulletHD.us

Term of Warranty:

From Date of Purchase

■ Date of Purchase:

Year

/Month

/Day

■ Dealer info:

Tel: _____

Manufacturer by: Silver Creation International Limited





Environmental friendly

Let's do something for our planet!!

Please download the drivers & software
from our official webpage.



www.BulletHD.us