

sTouch Board

User Guide



# Content

## Windows Version

- 3 **Main Menu**
- 5 Profile
  
- 6 **White Board**
- 8 Create new
- 9 Capture photo & Record video
- 10 Broadcast
- 11 Select color pen
- 12 Desktop mode
  
- 14 **Interactive room**
- 16 How to broadcast
- 17 How to be broadcasted
  
- 18 **Files**
- 19 Select/ delete/ Share
- 20 Captured picture
- 21 Play video

## Android version

- 23 Main
- 24 User name
- 25 Join a room

## Troubleshooting

- 27 Why my host room can not be found?
  
- 29 Why is the broadcasted screen lagging?
  
- 30 Error message ".NET Framework Initialization Error"
  
- 31 Documents can not be imported
  
- 32 Why is the recording video mute? How to change the microphone device?

# Windows Version

Windows 7, 8 ,8.1  
Supported

# Main Menu

## System Requirements

Operating System  
- Windows 7, Windows 8 and Windows 8.1

Hardware (Minimum)  
- 1.0 GHz processor or above (dual core processor recommended)  
- 1 GB RAM or above  
- 50 MB available hard disk space

Microsoft .Net Framework 4.0. If not installed, you can download from  
<http://www.microsoft.com/en-us/download/details.aspx?id=17718>

# sTouch Board

Tim 

profile

Start

Gallery

Interactive Room 




New

Create a New whiteboard



Import Document

Import PowerPoint, Word, XPS



Import Photo

Import a photo



**Digital White Board**  
Image based & intuitive user interface

- Select a background from default or your document
- Pen color or size selection
- Broadcast your screen content
- Record and capture your screen

Recent edited white board



Create a Room


Create a room to let other people to join

Broadcast



# User Profile

Click the user icon to edit your profile



Enter your name

Confirm your editing

Cancel the current edit

# White Board

← BACK to Main Menu

# Overview

Hide UI  
Minimize window  
Close APP  
Capture Photo/ Video

← Previous page

Next page →

New Page  
+

Pen sizes

Pen colors

Highlight

Color pen

Eraser

Clean all page



Redo

Undo

Broadcast  
📶



# Create New



Create a green, white, or black color background board


Import a photo as the background  
.Jpg/.png

Import a document  
PowerPoint/Word/XPS

Please make sure Microsoft office has installed in your computer



# Capture Photo & Record Video



Click the camera icon, the Photo and Video icons show up.

- Click the photo icon to take the current screenshot.
- Click the video icon to record the current screen. Also the sound can be recorded at the same time if the microphone device is installed. (for more how to setup the sound recording, please see the page 32 )

If the video recording has to be stopped, click the "STOP" icon to stop the recording.

To find the captured photo or recorded video, please go to the "More Files" from the main menu.



# Broadcast



Broadcast your screen and interact with the people who are in your interactive room.

- Tick: select the person to broadcast. To cancel, click the name again.
- Unlock/Lock: when a person is selected, you can unlock and pass your screen control to the person. So the user can control the content screen that you broadcasted. To switch lock or unlock, click the icon again. No more than one person is unlocked.
- Select All: select all to broadcast your screen to everyone on the list.
- Stop: Stop all the broadcasting



# Select Color



Click the rainbow color icon, the color palette shows up.  
Select a color to change your pen color



Select a color




side bar



## Desktop Mode

When minimize the AP window, the desktop mode UI will show up.

Thumbnail



Previous page


Click to the page

Next page


Color palette




### Default side bar



### Minimized side bar



### Maximized side bar



### Color palette



# Interactive Room

## Interactive Room

you can broadcast and interact your screen to whom are in your room.



Networking Requirements  
802.11n Wireless or  
100Mbps/higher Ethernet  
network

Broadcast Performance:  
The maximal allowable  
number of users for  
broadcast is:  
LAN(100Mbps) < 10  
Wi-Fi (802.11n) < 10



Windows NB

Devices have to be in the same local network.




Android tablet

# How to Broadcast

## Step 1

Click the button “+” to create a room, then other people can join your room.

Devices have to be in the same local network.




- Refresh: click the button “refresh” to refresh your list.
- Leave: click the “leave” button to leave the current room.

## Step 2

Click the broadcast button in whiteboard screen. You can start to broadcast your screen to other people who are in your room. Also, you can unlock one person to pass the control. So the user can control the content that you broadcasted.

No more than one person is unlocked.




# How to be Broadcasted


Click the button “+” to join a room, then you can see your name in the room which you have joined.  
So the host of the room can broadcast the screen to you.

Devices have to be in the same local network.

The name of the room host



Join one user's room



Leave the room

- Refresh: click the button “refresh” to refresh your list.
- Leave: click the “leave” button to leave the current room.

Files



# Files

ALL WhiteBoard Document Recorded Video Captured Picture User Guide

File types sorting



- Select: click the button "select" to start selecting the files. To cancel the selection, click the button "deselect" after clicking the select button.
- Delete: When a item is selected, then clicking the button "delete" to delete the selected files.

If you want to see where the files saved in your computer, please go to "Documents" folder, then you can find they are in "sTouch\_Board" folder.

Start to select items

Delete the selected files



Select



Delete





Captured picture



Export picture



Export





Recorded video

STOP



Play/Pause

Seek bar



Export Video





Export



# Android version

Android 4.0 or later supported





Waiting for broadcasting...

After joining a room, the user will see the words "waiting for broadcasting..." . That means the user has joined the room successfully and ready to be broadcasted.

Then the room host can broadcast the screen or pass control to the user.



# Troubleshooting

## Why my host room can not be found?


- 1) Checking your devices are in the same local network.
- 2) When the APP is opened at the first time, the windows system will ask you to allow the APP to communicate through Windows Firewall or not. Please click the "Allow access" button for the APP.



## Why my host room can not be found?

3) Go to "control panel/ all control panel items/ windows firewall/ allowed apps" and allow sTouch Board APP to communicate through Windows Firewall.

Tick



## Why is the broadcasted screen lagging?

The broadcasted screen performance depends on how many devices are connected. The fewer devices are connected, the higher performance you get. So the devices are sharing the total network bandwidth.


The actual speed of a network connection depends on many factors, such as the end devices being used, the quality of the cable, and the amount of network traffic.

## Error message “.NET Framework Initialization Error”

If the .NET Framework is not installed on your computer, a message will appear on the screen.

You can download from Microsoft's site:

<http://www.microsoft.com/en-us/download/details.aspx?id=17718>




## Documents can not be imported

Before importing documents, please make sure Microsoft Office has installed in your computer. PowerPoint, Word and XPS file formats are supported.

If your Microsoft Office version is 2007, you must have the Microsoft Save as XPS Add-in for 2007 Microsoft Office installed to convert files.

Download Microsoft Office 2007 Add-in: Microsoft Save as XPS:  
<http://www.microsoft.com/en-us/download/details.aspx?id=4791>



## Why is the recording video mute? How to change the microphone device?

### Step 1

Go to desktop tool bar, right click on the sound icon and select "Recording devices".



### Step 2

You can choose one microphone device for the sound recording. If the microphone is not installed, please use an extra microphone device.

