



Bandy One

1. Press button 1 down first then 4 and hold.
The green, blue and red LED's will start flashing in turn quickly.
2. Release both buttons.
3. Within 5 seconds press and hold one of the buttons on the Bandy One that you want to programme, at the same time press and hold the button of the transmitter you want to copy.
4. The remote control will check the frequencies, changing the LED colours as it does so.
5. The blue light will flash regularly to confirm the operation.